

Vorago®




SPORT BLUETOOTH EARBUDS 400



Guía rápida / Quick guide

ESPAÑOL

CONOCE TU DISPOSITIVO



ENCENDIDO

Saque los auriculares del estuche de carga / mantenga presionado el 5 segundos.

APAGADO

Coloque los auriculares en el estuche de carga, apague el dispositivo automáticamente / desconectado, toque el botón durante 5 segundos.

CONEXIÓN BLUETOOTH

CONEXIÓN ENTRE AURICULARES

- Los auriculares se conectarán automáticamente. La luz verde y blanca de los auricular maestro parpadeará alternativamente y los auriculares comenzarán a entrar en estado de emparejamiento.
- Abra el teléfono u otro dispositivo bluetooth, buque "ESB-400", haga clic y conectar. (Cuando el dispositivo se haya emparejado con éxito escuchará "conectado").
- Reconexión automática: Cuando vuelva a encender los auriculares se conectarán automáticamente al último dispositivo emparejado. (Siempre y cuando no hayan sido borrados del dispositivo).

CONEXIÓN DE AURICULARES INDIVIDUALES

- Saque los auriculares de su estuche de carga.
- Encienda el bluetooth de su dispositivo, busque el nombre "ESB-400" y haga clic para conectar. (Cuando el auricular y el dispositivo se conectan correctamente, la luz blanca parpadea continuamente y también se puede escuchar el tono de aviso "Conectado").

CONEXIÓN PARA DISPOSITIVOS

- Consulta el manual del usuario de tu dispositivo para activar bluetooth y ponerlo en modo de detección.
- Si el dispositivo solicita una contraseña, ingresa 0000.
- El LED azul del auricular parpadeará 2 veces cada 5 segundos, esto indica que está conectado y en funcionamiento.

ESTADO DE LA LUZ

Auriculares

Cargando: la luz verde encendida, Carga completa: la luz roja parpadea, Batería baja: la luz azul parpadea lentamente, Sin batería, la luz azul parpadea.

Estuche de carga

Cargando: la luz roja parpadea lentamente, Carga completa: la luz roja parpadea, Batería baja: la luz azul parpadea lentamente, Sin batería, la luz azul parpadea.

ESPECIFICACIONES TÉCNICAS

Rango de frecuencia:	20 Hz - 20 kHz
Sensibilidad:	96±3dB
Rango de frecuencia (mic):	30 Hz - 16 kHz
Sensibilidad (mic):	-38dB ± 3dB
Impedancia:	32 Ω
Conector:	Bluetooth, Micro USB
Alcance / BT Wireless:	10 m
Diámetro de bocinas:	13 mm
Batería:	Li-Polymer (3.7 V35 mAh x2)
Peso:	38 g
Compatibilidad:	Bluetooth 5.0
Carcasa de Carga:	600 mAh

- Mantenga el producto en un lugar seco, no lo exponga a condiciones húmedas para evitar cortocircuitos.
- No lo exponga al sol ni a altas temperaturas porque puede dañar o acortar la vida útil del producto, producir daños en la batería o deformar algunas piezas de plástico.
- No lo exponga a bajas temperaturas para evitar daños en los circuitos.
- No intente desarmar el producto.
- No golpee o deje caer el dispositivo por que puede provocar daños en el circuito electrónico interno.
- No utilice productos químicos como detergentes para limpiar el dispositivo.
- Evite cargar por más de 10 horas continuas el dispositivo ya que puede reducir la vida útil de la batería.

Garantía limitada de productos

Los equipos y/o accesorios Vorago están cubiertos por una garantía limitada por el tiempo indicado en la tabla de vigencia anexa, contando a partir de la fecha de adquisición, contra cualquier defecto de fabricación y funcionamiento, siempre y cuando hayan sido utilizado bajo condiciones normales de uso durante el periodo de la garantía y para lo cual fue fabricado. Vorago garantiza al comprador la ausencia de anomalías en lo referente a los materiales.

Productos	Vigencias
Equipos, tablets, celulares, audio, teclados, mouse, redes y accesorios	12 Meses
Monitores	36 Meses*
*Excepto en panel (display de pantalla) para el cual sólo será de 12 meses.	

Póliza de garantía Importante: Favor de leer y llenar esta póliza de garantía y sellarla en la tienda en la compra del producto.

Producto: Audífonos sport bluetooth	Sello del distribuidor
Modelo: ESB-400	
Marca: Vorago	
Número de serie:	
Número de factura:	
Fecha de entrega:	

Responsabilidades

La responsabilidad total de Vorago consistirá en reparar o reemplazar el producto, incluida la mano de obra y refacciones, sin ningún costo para el comprador cuando se devuelva al punto de venta, presentando esta póliza de garantía debidamente llenada y sellada por el establecimiento donde se adquirió el producto o copia del comprobante o recibo o factura, en el que consten los datos específicos del producto objeto de la compraventa, en los cuales se especifica la fecha de compra, para verificar los tiempos dentro de garantía. Vorago podrá utilizar piezas nuevas, restauradas o usadas en buenas condiciones para reparar o reemplazar cualquier producto, sin costo adicional para el consumidor. En el caso de equipos y/o accesorios que no tengan reparación, se generará el cambio por un producto similar o de características superiores. La presente garantía cubre los gastos de transportación del producto que derive de su cumplimiento; los cuales serán atribuibles directamente al proveedor del producto. En todo producto de reemplazo se renovará el periodo original de la garantía. Vorago se rige bajo las normas internacionales de fabricación de los productos.

Cómo obtener respaldo de la garantía

Los reclamos de garantía son procesados a través del punto de venta, durante los primeros 15 días posteriores a la compra, siempre y cuando cumplan con los requisitos. Los reclamos de garantía que no puedan ser procesados a través del punto de venta y toda inquietud relacionada con el producto adquirido deberán ser enviados con la guía prepagada por Vorago a la dirección de las oficinas centrales de Vorago en Francisco Villa No. 3, Col. San Agustín, C.P. 45645, Tlajomulco de Zúñiga, Jalisco, México.

Salvo en situaciones de fuerza mayor o caso fortuito, el tiempo de reparación en ningún caso será mayor a 30 días naturales contados a partir de la fecha de recepción del equipo en Vorago.

Exclusiones

Esta garantía no es válida en los siguientes casos:

- Cuando el producto se hubiese utilizado en condiciones distintas a las normales.
- Cuando el producto no hubiese sido operado de acuerdo con el instructivo de uso que se le acompaña.
- Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por parte de Vorago.

Vorago no ofrece ninguna otra garantía expresa para este producto.

Para hacer válida la garantía, así como la adquisición de partes, componentes, consumibles y accesorios.

Para hacer valida una garantía debe de enviarnos la siguiente información al correo: garantias@voragolive.com

- Modelo y color
 - Falla de producto
 - Ticket o factura de compra (digitalizado)
 - Su domicilio con C.P., teléfono y nombre completo.
- Disponibles en el establecimiento donde se adquirió el producto y/o en nuestras oficinas centrales

Vorago, S.A. de C.V.
Francisco Villa No. 3
Col. San Agustín, C.P. 45645
Tlajomulco de Zúñiga, Jalisco, México.
Tel. (33) 3044 6666

Importador:
Vorago, S.A. de C.V.
Francisco Villa No. 3
Col. San Agustín, C.P. 45645
Tlajomulco de Zúñiga, Jalisco, México.
Tel. (33) 3044 6666



www.voragolive.com

Limited product warranty

Vorago equipment and / or accessories are covered by a limited warranty for the time indicated in the annexed validity table, counting from the date of acquisition, against any manufacturing and operation defect, provided they have been used under normal conditions of use during the warranty period and for which it was manufactured. Vorago guarantees the buyer the absence of anomalies regarding the materials.

Products	Validity
PC, tablets, cell phones, audio, keyboards, mouse, networks and accessories	12 Months
LCD Monitor	36 Months*
* Except in panel (screen display) for which it will only be 12 months.	

Guarantee Policy Important: Please read and complete this warranty policy and seal it in the store when purchasing the product.

Product: Sport bluetooth earbuds	Dealer stamp
Model: ESB-400	
Brand: Vorago	
Serial number:	
Invoice number:	
Delivery date:	

Responsibilities

The total responsibility of Vorago will be to repair or replace the product, including labor and parts, at no cost to the buyer when it is returned to the point of sale, presenting this guarantee policy duly completed and stamped by the establishment where it was purchased. The product or copy of the receipt or receipt or invoice, in which the specific data of the product object of the sale, in which the date of purchase is specified, to verify the times within the guarantee. vorago may use new parts, restored or used in good condition to repair or replace any product, at no additional cost to the consumer. In the case of equipment and / or accessories that do not have repair, the change will be generated by a similar product or with superior characteristics. this guarantee covers the transportation expenses of the product derived from its fulfillment; which will be directly attributable to the supplier of the product.

In all replacement products, the original warranty period will be renewed. Vorago is governed by international standards for the manufacture of products.

How to obtain warranty support

Guarantee claims are processed through the point of sale, during the first 15 days after the purchase, as long as they meet the requirements. Guarantee claims that can not be processed through the point of sale and any concerns related to the product purchased should be sent with the prepaid guide by Vorago to the address of the Vorago headquarters in Francisco Villa No. 3, Col. San Agustín, CP 45645, Tlajomulco de Zúñiga, Jalisco, Mexico. Except in situations of force majeure or fortuitous event, the repair time in no case will be greater than 30 calendar days from the date of receipt of the equipment in Vorago.

Exclusions

This guarantee is not valid in the following cases:
 a) When the product had been used in conditions other than normal.
 b) When the product has not been operated in accordance with the instructions for use that accompany it.
 c) When the product has been altered or repaired by unauthorized persons by Vorago.

Vorago does not offer any other express warranty for this product.

To make the guarantee valid, as well as the acquisition of parts, components, consumables and accessories

To validate a guarantee, the following information must be sent to the email:

garantias@voragolive.com




- 1.- Model and color
- 2.- Product failure
- 3.-Ticket or purchase invoice (digitized)
- 4.-Your address with CP, telephone and full Name.

Available in the establishment where the product was purchased and / or in our central offices:

Vorago, S.A. de C.V.
 Francisco Villa No. 3
 Col. San Agustín, C.P. 45645
 Tlajomulco de Zúñiga, Jalisco, México.
 Tel. (33) 3044 6666

Importador:
 Vorago, S.A. de C.V.
 Francisco Villa No. 3
 Col. San Agustín, C.P. 45645
 Tlajomulco de Zúñiga, Jalisco, México.
 Tel. (33) 3044 6666

KNOW YOUR DEVICE



POWER ON

Take out earbuds from charging case / long touch the 5 second.
 Power off: Put earbuds into the charging case, turn off automatically / unconnected device, touch the button for 5 seconds.

CONNECTION BLUETOOTH

DOUBLE EARBUDS CONNECTION

1. When you take out two earbuds from charging case, earbuds will connect automatically. Master earbuds 'green and white light will flash alternately and earbuds start to enter pairing status. (Now earbuds are in pairing and you could open phone or connect other bluetooth devices.)
2. Open phone or other bluetooth devices, search "ESB-400, click it and connect. (When Bluetooth paired successfully, you will hear "connected")
3. Re-connect automatically: It will re-connect automatically to paired devices. (Premise is that devices 'Bluetooth is on and earbuds paired record still exist.)

SINGLE EARBUD CONNECTION

1. Take out one earbud from charging case.
2. Open mobile bluetooth, find pair name "ESB-400", click and connect. (When the earbud and phone connect successfully, white light continuous flashing and you could also hear prompt tone"Connected" .)

CONNECTIONS FOR DEVICES

- Check the user manual of your device to activate bluetooth and put it into detection mode. If the device requests a password enter 0000.
- The blue LED of the headset in operation 2 times every 5 seconds, this indicates that it is connected and in operation.

STATE OF THE LIGHT

Earbuds

Charging: green light on, Full charge: light off, Pairing: green and white light flashes.

Carrying case

Charging: the red light flashes slowly, Full charge: the red light flashes, Low battery: the blue light flashes slowly, Without battery, the blue light flashes.

TECHNICAL SPECIFICATIONS

Frequency range:	20 Hz - 20 kHz
Sensitivity:	96 ± 3dB
Frequency range (mic):	30 Hz - 16 kHz
Sensitivity (mic):	-38dB ± 3dB
Impedance:	32 Ω
Connector:	Bluetooth, Micro USB
Range / BT Wireless:	10 m
Horn diameter:	13 mm
Battery:	Li-Polymer (3.7 V35 mAh x2)
Weight:	38g
Compatibility:	Bt 5.0
Charging Case:	600 mAh

- Ⓢ Keep the product in a dry place, do not expose it to wet conditions to avoid short circuits.
- Ⓢ Do not expose it to the sun or high temperatures because it can damage or shorten the life of the product, damage the battery or deform some plastic parts.
- Ⓢ Do not expose it to low temperatures to avoid damage to the circuits.
- Ⓢ Do not attempt to disassemble the product.
- Ⓢ Do not hit or drop the device because it can cause damage to the internal electronic circuit.
- Ⓢ Do not use chemicals such as detergents to clean the device.
- Ⓢ Avoid charging the device for more than 10 hours since it can reduce the life of the battery.

Te invitamos a registrar tu producto y gozar de los beneficios, registra tu compra en nuestra página web y participa de las promociones en:

We invite you to register your product and enjoy the benefits. Register your purchase on our website and participate in promotions at:



www.voragolive.com



Queremos escucharte
 (33) 3044 6666
 COMUNICATE CON NOSOTROS

We want to hear you
 + 52 (33) 3044 6666
 CALL US



www.voragolive.com